


# Roller Displays


Please read and follow these instructions before use



1 Once you have purchased your ROLLER SCREEN display system please read and follow these instructions carefully.



5 Take the top of your media and insert it into the top trim media holder. Once you have done this tighten all grub screws.



2 Carefully unpack the unit from its carry bag. Make sure all pieces are there for construction;  
- Main unit  
- Retractable pole  
- Small allen key for screwing  
- Top trim media holder



6 Hold top trim media holder tight and release the pin in the main unit. Now your media is spring loaded and will retract. Piece together your retractable pole and guide it into the bottom hole. Hold the top trim media holder tight and extend up to the guide.




3 Take the pole and assemble, making sure the top has a guide for trim holding.



7 Now your ROLLER SCREEN display system is ready to use.

*Please not; Handle with care. When retracting back into the main unit do not let go of the top trim media holder until all of the media has completely retracted.*



4 Take the media tongue from the main unit and remove the liner from the double sided tape. Then affix the bottom of your media to the tongue. *Do not remove the pin until media and top trim are attached.*



8 Enjoy your ROLLER SCREEN display unit.